

STEPS TO CONFIGURE 1 BT TRANSCEIVER

Configuration is necessary for the use of the QN-UTSFP-1BT transceiver with models such as the QN-SW-225-8-4SFP, QN-IS-220-8FP & QN-IS-220-4FP.

Steps are as follows:

1. Insert transceiver to the Switch.
2. Insert RJ45 cable to the Transceiver.
3. Get access to the Switch using Console cable or SSH.



Note: After completion of above steps enter below commands:

```
console#configure
console(config)#interface <PORT_NAME>
console(config-if)#link-flap prevention disable
console(config-if)#shutdown
console(config-if)#no shutdown
console(config-if)#exit
console(config)#exit
```